

CURVE 1

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	112+08.00	-2.0%	-2.0%
END RUNOUT	112+59.00	-2.0%	0.0%
REVERSE CROWN	113+10.00	-2.0%	2.0%
BEGIN FULL SUPER	113+87.00	-5.0%	6.0%

CURVE 2

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END FULL SUPER	124+75.00	-5.0%	5.0%
REVERSE CROWN	125+52.00	-2.0%	2.0%
BEGIN RUNOUT	126+03.00	-2.0%	0.0%
BEGIN NORMAL CROWN	126+54.00	-2.0%	-2.0%

CURVE 3

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	143+69.00	-2.0%	-2.0%
END RUNOUT	144+20.00	-2.0%	0.0%
REVERSE CROWN	144+71.00	-2.0%	2.0%
BEGIN FULL SUPER	145+60.00	-5.5%	5.5%
END FULL SUPER	155+01.00	-5.5%	5.5%
REVERSE CROWN	155+90.00	-2.0%	2.0%
BEGIN RUNOUT	156+41.00	-2.0%	0.0%
BEGIN NORMAL CROWN	156+92.00	-2.0%	-2.0%

CURVE 4

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	159+13.00	-2.0%	-2.0%
END RUNOUT	159+64.00	0.0%	-2.0%
REVERSE CROWN	160+15.00	2.0%	-2.0%
BEGIN FULL SUPER	160+33.00	2.7%	-2.7%
END FULL SUPER	164+22.00	2.7%	-2.7%
REVERSE CROWN	164+40.00	2.0%	-2.0%
BEGIN RUNOUT	164+91.00	0.0%	-2.0%
BEGIN NORMAL CROWN	165+42.00	-2.0%	-2.0%

CURVE 5

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	179+23.00	-2.0%	-2.0%
END RUNOUT	179+74.00	0.0%	-2.0%
REVERSE CROWN	180+25.00	2.0%	-2.0%
BEGIN FULL SUPER	181+04.00	5.1%	-5.1%
END FULL SUPER	192+03.00	5.1%	-5.1%
REVERSE CROWN	192+82.00	2.0%	-2.0%
BEGIN RUNOUT	193+33.00	0.0%	-2.0%
BEGIN NORMAL CROWN	193+84.00	-2.0%	-2.0%

CURVE 6

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	205+18.00	-2.0%	-2.0%
END RUNOUT	205+69.00	0.0%	-2.0%
REVERSE CROWN	206+20.00	2.0%	-2.0%
BEGIN FULL SUPER	206+63.00	3.7%	-3.7%
END FULL SUPER	222+34.00	3.7%	-3.7%
REVERSE CROWN	222+77.00	2.0%	-2.0%
BEGIN RUNOUT	223+28.00	0.0%	-2.0%
BEGIN NORMAL CROWN	223+79.00	-2.0%	-2.0%

SUPERELEVATION TRANSITION TABLES REFERENCE THE SUPERELEVATION PERCENTAGES NOTED ON THE PLAN DETAILS. SUPERELEVATIONS LISTED ARE FROM AS-BUILT PLANS. FIELD VERIFY.

CURVE 7

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	243+91.00	-2.0%	-2.0%
END RUNOUT	244+42.00	-2.0%	0.0%
REVERSE CROWN	244+93.00	-2.0%	2.0%
BEGIN FULL SUPER	245+36.00	-3.7%	3.7%
END FULL SUPER	252+49.00	-3.7%	3.7%
REVERSE CROWN	252+92.00	-2.0%	2.0%
BEGIN RUNOUT	253+43.00	-2.0%	0.0%
BEGIN NORMAL CROWN	253+94.00	-2.0%	-2.0%

CURVE 8

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	258+56.00	-2.0%	-2.0%
END RUNOUT	259+07.00	0.0%	-2.0%
REVERSE CROWN	259+58.00	2.0%	-2.0%
BEGIN FULL SUPER	260+01.00	3.7%	-3.7%
END FULL SUPER	263+97.00	3.7%	-3.7%
REVERSE CROWN	264+40.00	2.0%	-2.0%
BEGIN RUNOUT	264+91.00	0.0%	-2.0%
BEGIN NORMAL CROWN	265+42.00	-2.0%	-2.0%

CURVE 9

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	278+83.00	-2.0%	-2.0%
END RUNOUT	279+34.00	-2.0%	0.0%
REVERSE CROWN	279+85.00	-2.0%	2.0%
BEGIN FULL SUPER	280+28.00	-3.7%	3.7%
END FULL SUPER	299+15.00	-3.7%	3.7%
REVERSE CROWN	299+58.00	-2.0%	2.0%
BEGIN RUNOUT	300+09.00	-2.0%	0.0%
BEGIN NORMAL CROWN	300+60.00	-2.0%	-2.0%

CURVE 10

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	302+56.00	-2.0%	-2.0%
END RUNOUT	303+07.00	0.0%	-2.0%
REVERSE CROWN	303+58.00	2.0%	-2.0%
BEGIN FULL SUPER	304+01.00	3.7%	-3.7%
END FULL SUPER	309+84.00	3.7%	-3.7%
REVERSE CROWN	310+27.00	2.0%	-2.0%
BEGIN RUNOUT	310+78.00	0.0%	-2.0%
BEGIN NORMAL CROWN	311+29.00	-2.0%	-2.0%

CURVE 11

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	314+81.00	-2.0%	-2.0%
END RUNOUT	315+32.00	0.0%	-2.0%
REVERSE CROWN	315+83.00	2.0%	-2.0%
BEGIN FULL SUPER	316+67.00	5.3%	-5.3%
END FULL SUPER	327+75.00	5.3%	-5.3%
REVERSE CROWN	328+59.00	2.0%	-2.0%
BEGIN RUNOUT	329+10.00	0.0%	-2.0%
BEGIN NORMAL CROWN	329+61.00	-2.0%	-2.0%

CURVE 12

SUPERELEVATION TABLE			
	STATION	LEFT LANE	RIGHT LANE
END NORMAL CROWN	332+67.00	-2.0%	-2.0%
END RUNOUT	333+18.00	-2.0%	0.0%
REVERSE CROWN	333+69.00	-2.0%	2.0%
BEGIN FULL SUPER	334+71.00	-6.0%	6.0%
END FULL SUPER	347+47.00	-6.0%	6.0%
REVERSE CROWN	348+49.00	-2.0%	2.0%
BEGIN RUNOUT	349+00.00	-2.0%	0.0%
BEGIN NORMAL CROWN	349+51.00	-2.0%	-2.0%

SUPERELEVATION TRANSITION TABLES REFERENCE THE SUPERELEVATION PERCENTAGES NOTED ON THE PLAN DETAILS. SUPERELEVATIONS LISTED ARE FROM AS-BUILT PLANS. FIELD VERIFY.